



# VersaLoft **Assembly Instructions Regular Bed: Twin or Full**

## Tools Needed:

Square Drive Bit  
Power Screw Driver

## Parts List:

2 - Headboards  
2 - Side Rails  
4 - Legs  
1 - Slat Roll  
4 - Wooden Caps (Twin Bed)  
8 - Wooden Caps (Full Bed)

## Hardware List:

 1 - Allen Wrench  
 8 - 4" Bolts  
 8 - 2 3/4" Bolts  
 30 - 1 1/2" Screws  
 8 - Dowel Nuts



Figure 1



Figure 2



**Step 1:** Attach legs to headboards using 8 - 4" bolts. Tighten with the Allen Wrench. Fasten ends of headboard caps to top of legs with 4 - 1 1/2" screws in small predrilled holes (See figure 1).

**Step 2:** Insert dowel nuts into holes on inside of side rails. Attach the headboards to the side rails with 8 - 2 3/4" bolts, turning bolts into dowel nuts with the Allen wrench. (Do not over tighten).

**Step 3:** Lay the slat roll in the bed frame with the slat string facing up. Attach with the 1 1/2" screws. (See figure 2). Put wooden caps in holes in headboard caps. Twin bed gets 4 caps - full bed gets 8 caps. These caps are taken out and metal dowels put in if you wish to purchase another bed to use as a bunkbed.

**Beds need a standard Twin or Full mattress.**