



GRONOMICS® “TOOL FREE ASSEMBLY”

18” x 34”x 32” ELEVATED GARDEN BED Parts Check List and Assembly Instructions

STEP I

- A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #EGB18-34
Model #EGB18-34S

QUANTITY	PART DESCRIPTION	PART #
4	4” x 4” x 32” Corner Post	3201
4	4½” x 4½” x 1½” Post Cap	3100
Parts for Sides		
4	14½” x 5½” x 1” Side Rail	1450
2	14½” x 2½” x 1” Narrow Center Side Rail	1451
2	31” x 5½” x 1” Side Rails with Cleat	3102
2	31” x 2½” x 1” Narrow Center Side Rail	3103
2	31” x 5½” x 1” Side Rail (One w/Logo)	3101, 3101L
Parts for the Bottom		
2	15½” x 4½” x 1” Corner Notched Bottom Board	1551
4	15½” x 5½” x 1” Bottom Board	1550
1	18” x 34” Fabric Liner	2002
Packaged & Inspected by: _____ Date _____		

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@gronomics.com or phone at 763-753-7374.



GRONOMICS® “TOOL FREE ASSEMBLY”

STEP II

- A) Start by standing up two of the four 4” x 4” x 32” posts.
- B) Slide a 31” x 5½” x 1” side rail with cleat on bottom between the posts. (see figure 1)
- C) Repeat the same process with the other two 4” x 4” x 32” posts and 31” x 5½” x 1” side rail with cleat. (see figure1)

Soil depth options: The directions as printed will provide an elevated bed with a soil depth of approximately 10”. If you want a soil depth of approximately 6”, just reverse the position of the lower side rail with the cleat on top.

STEP III

- A) Connect the two sets of corner posts by sliding a 14½” x 5½” x 1” side rail into each post. (see figure 2)

STEP IV

- A) Slide both of the 31” x 2½” x 1” narrow center rails between the posts on both ends. Do the same with the two 14½” x 2½” x 1” narrow center rails.

Repeat step IV using the last two 14½” x 5½” x 1” side rails and the 31” x 5½” x 1” side rails.

Note: Placement for the 14½” x 5½” x 1” side rail with logo. (see figure 3)

STEP V

- A) Place the two 15½” x 4½” x 1” corner notched bottom boards on the end cleats. Make sure the corner cut-out notches are in the corners.
- B) Place the remaining 15½” x 5½” x 1” bottom boards on the cleats. (Gap between boards allows water drainage.)

STEP VI

- A) Carefully remove the screw covers that are protecting the cap screws. Place the cap on the center of the screw utilizing the pre-drilled hole in bottom of the cap. Do not over tighten. (see figure 3)
- B) Place the fabric liner on the bottom.

(Figure 1)



(Figure2)



(Figure 3)



1-Year Warranty: All Gronomics® products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.