


ISLAND BAY™

ITEM NAME: 15ft Hammock Stand for Spreader Bar
Hammocks

SKU: HSHS10-Bronze, HSHS10-Pewter, HSHS10-GC,
HSHS10-TC, HSHS10-3, HSHS10-4

ASSEMBLY INSTRUCTIONS



CONTENTS OF PACKAGE:



End Plugs are pre-installed on foot brackets and arm poles.

2pcs of upright arm poles (a)

2pcs of foot brackets (c)

1pc of base pole (b)

2pcs of S-hooks (d)

PRE-ASSEMBLY PREPARATION:



DO NOT LET CHILDREN PLAY IN OR AROUND THE UNIT DUE TO THE POSSIBLE RISK OF FINGER ENTRAPMENT

- Please read through this instruction before beginning assembly.
- Two-adult assembly is recommended.
- Clear out the space for assembly and lay out all parts based on Parts List, extra room will allow you to easily determine if all the pieces are present.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- Keep small parts and pieces away from children until fully assembled.
- Please check for any loose screws and tighten them before you use.

STEP-BY-STEP ASSEMBLY:

STEP 1: Place base pole (b) between the two foot brackets (c), and insert foot brackets into the pole. Check to make sure the pre-installed spring clips have snapped in securely to the hole on the base pole.

STEP 2: Take one arm pole (a) and hold it with the plugged end facing up.

STEP 3: Slide it over one of the foot bracket ends facing up. Make sure the pre-installed spring clip has snapped in securely to the hole on the arm.

STEP 4: Repeat for the other arm pole. You may want to grasp the end of each pole and shake gently to insure all connections are secure. **CAUTION:** All foot brackets must be completely inserted into the poles to ensure safety and proper stand measurements.

STEP 5: Next insert the S-hooks that are included, into the holes at the top of each arm pole. This is done by inserting the hook perpendicular to the pole and turning it to align with the pole. Now you are ready to attach your hammock to the stand.

CAUTION – PLEASE READ CAREFULLY

All poles must be installed 2 ½ inches onto brackets.

Locate the stand on a level area of your yard.

Do not pull or drag your hammock stand when moving or adjusting it.

After any moving or adjusting of stand, always inspect it to make sure that the joints are properly inserted. Failure to do so may result in the hammock stand collapsing upon use.

Examine your stand at least every three months to ensure the pole plugs are still in place and that all welded joints are fully intact.

Do not exceed load limit of 450lbs or recommended load limit of hammock – whichever is less

Always lift stand from both ends

Never leave children playing or around hammock stand unattended.

Manufacturer Warranty:

Products are guaranteed to be free of defects in workmanship and materials for up to one year after purchase date. Manufacturer is not responsible for rot or decay caused by natural elements and wet climate conditions. It is suggested to remove stand from elements when not in use. Damage caused by normal wear, improper care including storage, maintenance and installation is not covered.

For assistance with assembly, please contact customer service 1-888-880-4884