



# hayneedle



**ITEM NAME :** Willow Bay Wicker Rocking Chair

**SKU :** CWR101-1,CWR141-1,CWR142-1




Dimensions:  
25"(L) x 28"(W) x 39.5"(H)


**For assistance with assembly, please contact  
Hayneedle Customer Care Center  
1-888-880-4884**

## STEP-BY-STEP ASSEMBLY:

**STEP 1** To unfold the rocker, properly position the rocker upright, then push the back and the arm of the rocker with mild force.



**STEP 2** After unfolding the rocker, please rotate the safe lock anticlockwise to lock tightly.



To fold the rocker , please repeat the opposite procedure.

**Weight Limit:  
Not to exceed 250 pounds**



**For assistance with assembly, please contact customer service  
1-888-880-4884**