

22578 Part List

No.	Part	Description
1.	15444	Leg Tube
2.	15445	Leg Tube
3.	15460	Connect Piece
4.	15461	Connect Piece
5.	15483	Grnme Tach
6.	15217	Self Drive Bolt
7.	15296	Plug For Leg Tube
8.	15238	Corner Cover For Leg Tube
9.	15360	Inner Washer For Leg Tube
10.	15297	Inner Washer For Leg Tube
11.	15443	Leg Tube
12.	15448	Gemel
13.	15449	Gemel
14.	15450	Gemel
15.	15298	Slide Connector For Leg Tube
16.	15452	Slide Tube
17.	15453	Slide Tube
18.	15253	Hex Bolt
19.	15251	Hex Bolt
20.	15255	Hex Bolt
21.	15484	Nut
22.	10431	Anchor
23.	15379	Spring Pin
24.	15380	Spring Pin
25.	15481	Spring Pin
26.	15258	Top Crest
27.	15259	Plug For Gemel
28.	15260	Gemel Corner Bush
29.	15482	PP Washer
30.	15455	Cover
31.	15485	Bag
32.	15454	Inclined Holding Tube

