

hayneedle

ITEM NAME: Siesta 3 Person Canopy Swing Bed

SKU: RELC0033/RELC0034



































For assistance with assembly, please contact
Hayneedle Customer Care Center
1-888-880-4884

PRE-ASSEMBLY PREPARATION:

- Assemble requires 3 people
 - Tools are not included in packaging.
 - Before assembly, ensure all parts are present and not damaged.
1. Assemble on a flat, hard, and even surface
 2. Keep canopy swing away from fire or inflammable objects
 3. To avoid injury during use, follow these guidelines:
 - a. Do not put arms or legs between seating area and frame of canopy swing.
 - b. Do not put any objects directly in front or behind the canopy swing.
 - c. Use canopy swing on a flat, unobstructed surface Excessive swinging will cause the swing to collapse and may result in injury to persons nearby
 4. Maximum load is 550 lbs.
 5. Only allow children to use the canopy under adult supervision.
 6. Occasionally check sun bed for loose screws, tighten before using.
 7. Cover canopy during wet and/or windy weather.


Hardware List, Tools Required and Structural Diagram

NO	PICTURES OF PARTS	QUANTITY	NO	PICTURES OF PARTS	QUANTITY
1	 (Front)	2pcs	9		1pcs
2	 (Behind)	2pcs	10		1pcs
3		1pcs	11		2pcs
4		1pcs	12		2pcs
5-1		1pcs	13	 Seat	1pcs
5-2		1pcs	14		3pcs
6		2pcs	15		2pcs
7		2pcs	16	 Canopy	1pcs
8		1pcs	17	 Cushion	1pcs

CODE	PICTURES OF PARTS	QUANTITY	CODE	PICTURES OF PARTS	QUANTITY
A		2	H	 0.24"x2.16"	6
B	 0.32"x3.74"	4	I	 0.24"x1.77"	2
C	 0.32"x1.38"	2	J	 0.24"x1.38"	4
D	 0.32"x0.98"	4	K	 0.24"x1.18"	3
E	 0.24"x3.15"	2	L	 0.24"x0.98"	4
F	 0.24"x2.95"	2	M		4
G	 0.24"x2.36"	2	N		2


STEP-BY-STEP ASSEMBLY:

Step 1. Join part 1, 2 & 3 using hardware part B




Step 2. Join Part 5-1 & 5-2 by K:0.24"x1.18".

Join parts 4, 5, & 6 by the hardware part E, F and H




Step 3. Join parts 7, 8, 9, and part 10 by the hardware part I and L




Step 4. Join parts 11, 12, and 13 by the hardware parts C, D, and J.

The chair can be turned into a bed by adjusting the parts G and M.



Step 5. Join part 14 (3 tubes) and part 15 together. Put Part 14 and Part 15 on the swing by hardware K and N.



Step 6. Hang the seat on the steel frame by part A, then put the legs of Part 15 into the corners of part 16 (canopy).



Step 7. Seat is covered with part 17 (seat cover). Part 17 (seat cover) is fixed to the seat by the ties.



Step 8. The chair can be extended to a bed.





For assistance with assembly, please contact customer service
1-888-880-4884