



FIBERBUILT UMBRELLAS™

90LB UMBRELLA BASE FILLING INSTRUCTIONS

PARTS INCLUDED

- 1 Aluminum Sleeve
- 2 Concrete Anchor Bolts
- 1 3/16" Screw Pin with Nut

TOOLS REQUIRED

- 1 80lb Bags of High Density Concrete
- 5 Gallon Bucket
- Drill & 3/16 drill bit

STEP-BY-STEP INSTRUCTIONS

- 1) Remove umbrella base and parts from box. Do not remove cardboard protector on base sleeve.
- 2) Place umbrella base upside down on the 5 gallon bucket (fig. 1).
- 3) Place concrete anchor bolts provided into sleeve making sure nut is at the top with the washer below.
NOTE: DO NOT REMOVE CARDBOARD FROM SLEEVE.
- 4) Affix the anchor bolts with nut to the sleeve. Allow the washer to fall down to the bottom part of the bolt for the best anchoring results. (fig. 2).
- 5) Insert aluminum sleeve with the cardboard still attached into hole provided so that the rectangular plate sits flush against the hole. The cardboard will help prevent the concrete from reaching the bolts (fig. 3).
- 6) Mix concrete according to directions on bag. **For best results, use crack resistant 5000 PSI concrete.**
- 7) Pour mixed concrete into base except inside area protected by the cardboard. Distribute evenly until it is flush with the bottom lip of the umbrella base.
- 8) Let the base set, in the present position, until the time specified on bag of concrete.
- 9) After concrete has set, tighten up the nut anchoring the base plate and remove cardboard strip.
- 10) Turn base right side up and insert the bottom pole of the umbrella.
- 11) Using drill and drill bit, drill hole into umbrella pole through existing hole in aluminum sleeve and secure pole with screw pin and nut (fig.4 & fig 5).




Figure 1



Figure 2




Figure 3




Figure 4



Figure 5

Flexibility Is Our Greatest Strength™



FIBERBUILT UMBRELLAS™

125LB UMBRELLA BASE FILLING INSTRUCTIONS

PARTS INCLUDED

- 1 Aluminum Sleeve
- 2 Concrete Anchor Bolts
- 1 3/16" Screw Pin with Nut

TOOLS REQUIRED

- 1 ½ 80lb Bags of High Density Concrete
- 5 Gallon Bucket
- Drill & 3/16 drill bit

STEP-BY-STEP INSTRUCTIONS

- 1) Remove umbrella base and parts from box. Do not remove cardboard protector on base sleeve.
- 2) Place umbrella base upside down on the 5 gallon bucket (fig. 1).
- 3) Place concrete anchor bolts provided into sleeve making sure nut is at the top with the washer below.
NOTE: DO NOT REMOVE CARDBOARD FROM SLEEVE.
- 4) Affix the anchor bolts with nut to the sleeve. Allow the washer to fall down to the bottom part of the bolt for the best anchoring results. (fig. 2).
- 5) Insert aluminum sleeve with the cardboard still attached into hole provided so that the rectangular plate sits flush against the hole. The cardboard will help prevent the concrete from reaching the bolts (fig. 3).
- 6) Mix concrete according to directions on bag. **For best results, use crack resistant 5000 PSI concrete.**
- 7) Pour mixed concrete into base except inside area protected by the cardboard. Distribute evenly until it is flush with the bottom lip of the umbrella base.
- 8) Let the base set, in the present position, until the time specified on bag of concrete.
- 9) After concrete has set, tighten up the nut anchoring the base plate and remove cardboard strip.
- 10) Turn base right side up and insert the bottom pole of the umbrella.
- 11) Using drill and drill bit, drill hole into umbrella pole through existing hole in aluminum sleeve and secure pole with screw pin and nut (fig.4 & fig 5).




Figure 1



Figure 2




Figure 3




Figure 4




Figure 5

Flexibility Is Our Greatest Strength™



FIBERBUILT UMBRELLAS™

175LB UMBRELLA BASE FILLING INSTRUCTIONS

PARTS INCLUDED

- 1 Aluminum Sleeve
- 2 Concrete Anchor Bolts
- 1 3/16" Screw Pin with Nut

TOOLS REQUIRED

- 2 80lb Bags of High Density Concrete
- 5 Gallon Bucket
- Drill & 3/16 drill bit

STEP-BY-STEP INSTRUCTIONS

- 1) Remove umbrella base and parts from box. Do not remove cardboard protector on base sleeve.
- 2) Place umbrella base upside down on the 5 gallon bucket (fig. 1).
- 3) Place concrete anchor bolts provided into sleeve making sure nut is at the top with the washer below.
NOTE: DO NOT REMOVE CARDBOARD FROM SLEEVE.
- 4) Affix the anchor bolts with nut to the sleeve. Allow the washer to fall down to the bottom part of the bolt for the best anchoring results. (fig. 2).
- 5) Insert aluminum sleeve with the cardboard still attached into hole provided so that the rectangular plate sits flush against the hole. The cardboard will help prevent the concrete from reaching the bolts (fig. 3).
- 6) Mix concrete according to directions on bag. **For best results, use crack resistant 5000 PSI concrete.**
- 7) Pour mixed concrete into base except inside area protected by the cardboard. Distribute evenly until it is flush with the bottom lip of the umbrella base.
- 8) Let the base set, in the present position, until the time specified on bag of concrete.
- 9) After concrete has set, tighten up the nut anchoring the base plate and remove cardboard strip.
- 10) Turn base right side up and insert the bottom pole of the umbrella.
- 11) Using drill and drill bit, drill hole into umbrella pole through existing hole in aluminum sleeve and secure pole with screw pin and nut (fig.4 & fig 5).




Figure 1



Figure 2




Figure 3




Figure 4




Figure 5

Flexibility Is Our Greatest Strength™