

LIFETIME TABLE/CHAIR LIMITED FACTORY WARRANTY

**THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS
IF PARTS ARE UNAVAILABLE OR OBSOLETE.**

1. Lifetime Folding Tables/ Chairs are warranted to the original purchaser to be free from defects in material or workmanship for a period of Two, Five, or Ten years (depending on the model) from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to alteration or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.
2. This warranty is nontransferable and is expressly limited to the repair or replacement of defective product. If the product is defective within the terms of this warranty, Lifetime Products, Inc. will repair or replace defective parts at no cost to the purchaser. Shipping charges to and from the factory are not covered and are the responsibility of the purchaser.
3. This warranty does not cover scratching, scuffing or other cosmetic damage that may result from normal use of the product. In addition, defects resulting from intentional damage, negligence or unreasonable use will void this warranty.
4. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in all products, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
5. This warranty is in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Neither Lifetime Products, Inc. nor any representative assumes any other liability in connection with this product.

ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY A SALES RECEIPT.

REPORT PRODUCT DEFECTS IN WRITING TO:

Lifetime Products In., Attn: Warranty Dept., PO Box 160010, Clearfield, UT 84016-0010 or call (800)225-3865 M-F 7a.m. to 5p.m MST. Or Email: warrantyclaims@lifetime.com.

Each claim needs a copy of the original sales receipt, a picture of the entire table or chair, and two different views of the damages. If filing for more than one item please contact Customer Service Dept. for instructions on how to file your claim.



Exceeds Commercial and Institutional Standards

Chair Standards

The Business and Institutional Furniture Manufacturer's Association (BIFMA) sets industry standards for commercial-grade furniture. The standards are intended to provide manufacturers and users with a common basis for evaluating safety, durability, and the structural adequacy of the specified furniture. The standards define specific tests, laboratory equipment to be used, formulas to determine weight or height to use in each test, the conditions of testing, and the acceptance levels to be used in evaluating these products.

1. **Back Strength Functional Load-** The chair is restrained from movement and 150 lbs of force is applied to the chair back for a period of one minute. The chair passes if there is no structural breakage or loss of serviceability, including stacking ability.
2. **Back Strength Proof Load-** The chair is restrained from movement and 250 lbs of force is applied to the chair back. The chair passes if there is no sudden change in the structural integrity of the product. Loss of serviceability is acceptable.
3. **Stability Test (Backward)-** A 173 lb weight is strapped to the chair as if an adult male was sitting in the chair. The rear legs of the chair are blocked. A rear load is applied to the chair until the total weight is transferred to the rear legs. The chair passes if the force required is greater than 35 lbs.
4. **Stability Test (Forward)-** The front legs of the chair are blocked and a force is applied downward at 45° from the surface of the seat. The chair passes if the force required is greater than 40% of the total chair weight.
5. **Chair Leg Strength Functional Load (Side)-** The entire chair is restrained on its side. A 75 lb weight is applied one inch from the bottom of the front leg for one minute. This is repeated on the back leg. The chair passes if there is no structural breakage or loss of serviceability.
6. **Chair Leg Strength Proof Load (Side)-** The entire chair is restrained on its side. A 115 lb weight is applied one inch from the bottom of the front leg for one minute. This is repeated on the back leg. The chair passes if there is no sudden change in the structural integrity of the product. Loss of serviceability is acceptable.
7. **Chair Drop Functional Load-** A 225 lb weight is positioned 6 inches above the seat of the chair and allowed to free-fall onto the center of the seat. The chair passes if there is no structural breakage or loss of serviceability.
8. **Chair Drop Proof Load-** A 300 lb weight is positioned 6 inches above the seat of the chair and allowed to free-fall onto the center of the seat. The chair passes if there is no sudden change in the structural integrity of the product. Loss of serviceability is acceptable.
9. **Seating Impact Test-** A 125 lb weight is dropped from a height of 2 inches onto the surface of the chair seat for 100,000 cycles. The chair passes if there is no structural breakage or loss of serviceability.

